Installation Instructions – Premier[™] Melt Stick

Premier[™] Melt Stick

Application:

Premier[™] Melt Stick is a meltable, co-polymer based adhesive used for small superficial damages (scratches) in the polyethylene coating, where the damage does not extend to the bare metal.

Delivery range:

Repair stick 25 x 300 mm 36 pcs. / box





Remove any non-adherent factory coating and chamfer sharp edges with a rasp (semi-circular blade)



Clean and roughen the surface with a hand wire brush.



Warm up the factory coating.




Roughen again the warmed factory coating.

Smooth the material with a hot spatula.

7



Preheat the repair stick with a flame until the material is soft. A light ignition of the repair stick is acceptable.



The material of the repair stick must cover and fill out the repair area. The full firmness of the polyethylene stick is only obtained after 2 h minimum.



Continuously warm the repair stick and the area to be repaired.

Attention: Our coating systems are not suitable for the sealing of leakages in media transporting pipelines, but exclusively for the prevention and protection from corrosion.

